

MLAC05 BP Amp to Deltran II Cable

Spare Parts

An adapter cable for connecting the MLT0670 Disposable BP Transducer (stopcock) to the ML117 BP Amp.



Caution

Read “Statement of Intended Use” on our website or in “Getting Started with PowerLab” before use.

Ordering Information:

MLAC05 BP Amp to Deltran II cable

For use with:

ML117 BP Amp

MLT0670 Disposable BP Transducer (stopcock)